

No Water, No Problems!

Powersports Product Data Sheet

Description

Waterless Engine Coolant for MX, trial & enduro bikes.

Application

For use in all track, trail and MX bike engines primarily fabricated from aluminium with steel and copper components.

Typical Characteristics

Physical State : Low Viscosity Synthetic Liquid

Boiling Point : Above 180°C

Freezing Point : Below -40°C

Colour : Red clear

Odour : Almost odourless

Taste : Slightly Sweet, Non-Toxic but not recommended for human consumption

4-Life Durability

Hawk Waterless Engine Coolants have been proven to last >20 years and a million miles in service without the need for replacement.

ASTM & ISO Standards

Hawk in association with ASTM committee D15.22 have developed a specific range of standards for waterless engine coolants. All Hawk Coolants are manufactured in accordance with certified ISO procedural standards.

Availability

In 2, 5, 25, 205 and 1000 Litre containers

Health and Safety

Toxicity : Non-Toxic

Environmental : Bio-degradable

Flammability : Not classed as flammable

Transport : Not classed as hazardous for transport

For more H&S information please refer to Hawk SDS PS180-SDS.

For detailed product information on Power Sports 180° please visit hawkwaterlesscoolants.com



Benefits over water-based coolants

Eliminates Overheating

Hawk Waterless Coolants have a boiling point above 180°C and will not vaporise, thus eliminating overheating, boil-over and after-boil.

Reduces Pressure

Hawk Waterless Coolants generate very low vapour pressures reducing strain on engine hoses and cooling system components.

Prevents Corrosion

Water promotes corrosion via oxidation and electrolysis - Hawk Waterless Coolants contain no oxygen and are virtually non-conductive effectively preventing corrosion.

Maximise BHP

Hawk Waterless Coolants eliminate pre-ignition and detonation caused by overheating - thus increasing combustion efficiency and delivering more power.

Stops Erosion

Hawk Waterless Coolants stop cavitation and eliminate liner and cooling pump erosion.

Freeze Protection

Hawk Waterless Coolants freeze below -40°C

Non-Toxic

Hawk Waterless Coolants are proven to be Non-Toxic. Standard anti-freeze is toxic and known to kill pets.

In technical partnership with

Honda Racing

Fluid Conversion Process: From Water-Based to Hawk Waterless Engine Coolant

The primary objective of converting to Hawk Waterless Engine Coolant is to eliminate all of the problems associated to water, whilst increasing reliability and engine life. Specifically, to prevent overheating, corrosion, erosion, pressurisation and detonation.

Conversion from a water-based coolant to Hawk is a straight forward process that can be undertaken by anyone with some basic experience in engine mechanics, provided the instructions below are adhered to. The time to complete a conversion will depend on several factors including experience, engine design, and workshop/tool facilities – we recommend the DIY enthusiast allow 2 hours and a professional mechanic 1 hour. If several engines are to be converted simultaneously then the average time taken will reduce with confidence and practice – Hawk technicians usually complete a bike engine conversion in 60 minutes, sometimes less.

If the engine to be converted is currently filled with a water-based coolant then a two-step procedure is involved, Steps 1 – 24 below. However if the engine is 'dry' then it's a simple case of filling with the appropriate Hawk coolant and making sure all air has been vented from the cooling system, Steps 22 – 24 below.

Hawk Prep Fluid is specifically formulated to hygroscopically absorb any water-based coolant remaining in the cooling system after initial drain. Because certain parts of the cooling system might not drain out with gravity, and it would take too long to disconnect every pipe etc., installing a scavenging fluid is the most practical method of removing all the water-based coolant. The Prep Fluid is not formulated to chemically clean the engine of rust and scale, but the process of circulation and draining will help remove any loose sediment.

If you have any questions prior to or during the conversion process please feel free to contact Hawk HQ or any of our accredited conversion centres.

1. Do not work on a hot engine, wear appropriate safety gear and read all the instructions before doing anything.
2. Whenever possible verify the total cooling system capacity, to ensure you have sufficient Prep Fluid and/or Hawk coolant to complete the conversion. If it is not possible to confirm the capacity then drain the cooling system and measure how much fluid comes out – add 10% for coolant that cannot be drained.
3. Locate cooling system drain-valve or drain-plug and check it operates and/or is not seized etc. – there is no point proceeding if the engine cannot be drained.
4. Run engine up to operating temperature and where appropriate open (and leave open) all heater-matrix controls.
5. Once up to temperature and pressure inspect cooling system components to identify any existing leaks or badly worn components.
6. Where necessary carry out repairs to ensure the engine coolant is retained inside the cooling system – this step is appropriate whether converting to Hawk or changing out any coolant.
Note: Hawk coolants will exert very little pressure on hoses, radiator seams etc. but if a small leak or drip is evident better to replace the faulty part prior to conversion.
7. Allow engine and coolant to cool.
8. Carefully remove the radiator or expansion tank cap.
9. Place a suitable tray underneath the drain-valve or drain-plug.
10. Open drain valve or remove drain plug and allow water-based coolant to gravity drain. This might take several minutes.
11. Once the majority of water-based coolant has been drained it is often beneficial to release the radiator top-hose (clip) and introduce some low pressure compressed air. This is not absolutely necessary as the Prep Fluid will absorb any remaining water, however if 90-98% of the water-based coolant can be removed on first-drain the Prep Fluid can be used two or more times.
12. Once all the water-based coolant has been drained, verify the volume (in litres or pints) and then dispose of in accordance with associated Hawk Safety Data Sheet - available on request.
13. As recommended in Step 6, replace or repair any obviously faulty or leaking cooling system components.
14. Close the drain-valve or replace the drain-plug. Reconnect the top-hose and tighten any clips etc.
15. Fill the cooling system with sufficient Prep Fluid to ensure effective circulation around the complete system. Although it is sometimes possible to use less Prep Fluid than the total system volume, our recommendation is to fill to normal levels.
16. Leave the radiator or expansion tank cap off, as this will enable any trapped air to be vented.
17. Run engine up to operating temperature.
18. As the engine and coolant temperature rises then the coolant will expand. Also, as air is vented from the system it may displace coolant from the radiator or expansion tank. Take appropriate measures to prevent Prep Fluid (or coolant) from dripping onto the exhaust system. Both 50-50 water-based coolants and Hawk Coolants can combust under extreme circumstances, including contact with a very (almost red) hot exhaust.
19. Once all air has been vented and the Prep Fluid has been topped up to the normal working level, then replace the radiator or expansion tank cap.
20. Inspect cooling system components for leaks. As mentioned in Step 6, Hawk coolants exert much less pressure than water-based coolants so the tendency is to prevent leaks. However if the engine to be converted has a predisposition to leak we recommend running the Prep Fluid for a week to verify system integrity.
21. Repeat steps 7 – 12 (substituting references of water-based coolant with Prep Fluid). As mentioned the Prep Fluid has the potential to be used several times, provided it is stored in a sealed container.
22. Fill the cooling system with the appropriate Hawk coolant for the engine. E.g. Powersports for track, trail and MX bikes, Aero Cool 180° for Rotax aircraft engines, etc. Fill to the same Level Mark as used for water-based coolants.
Note: Hawk coolants expand by approx 7% by volume, compared with 6% by volume for 50-50 water-based coolants, but they generate ¼ of the vapour pressure.
23. Repeat steps 14 – 19 (substituting references of Prep Fluid with Hawk Coolant).
24. Affix the aluminium backed 'Hawk - Do Not Add Water' red sticker to the radiator/expansion tank cap, plus additional plastic stickers within the engine bay or adjacent bulk-heads.
25. In the event of engine maintenance, that requires draining of the cooling system, ensure the Hawk Coolant is captured and stored in a sealed container prior to refilling and recommissioning of the engine. This is to prevent hygroscopic absorption of water-borne moisture that will reduce the benefits of using a waterless engine coolant.

If you would like any clarification or assistance with these instructions please call us on 01792 572299 or send an email to info@hawkwaterlesscoolants.com